



- 1. Make sure your USB stick is 2gb or less; this is the maximum FAT16 partition size.
- 2. Navigate to My Computer and double-click it.
 - a. This is also sometimes called "Computer" or "This PC":



3. Right-click on your USB drive:




4. Select "Format..." in the context menu:



Shop Floor Automations, Inc. 5360 Jackson Drive, Suite 202 La Mesa, CA 91942-6003

Phone: (619) 461-4000 Toll Free: (877) 611-5825 Fax: (619) 461-5918 5. Set the drive to be formatted as "FAT-16," also sometimes called "FAT" (not "FAT-32").



6. Once formatted, the USB drive should work properly in your Floppy Emulator.

Web: www.shopfloorautomations.com **Email:** support@shopfloorautomations.com